
PC-6 Landing gear

☐ Cut the 4-40 threaded rod and weld to the 4-40 Coupler.

☐ Glue the graphite tube with the steel rod, using epoxy or CA.


☐ Glue the aluminium bushing #PC6-L12, on the graphite tube.




☐ Glue the Lower strut head (#PC6-L14) into the Lower oleo strut (#PC6-LA) with JB Weld or **30 min** Epoxy




☐ Drill Ø1/8" hole in the piston.



☐ Insert the Lower strut hand (#PC6-L11) into the Lower oleo strut (#PC6-LA). Drill Ø1/8" hole for the SHCS 4-40 x 3/4"





Herodesign
Martin Rousseau

03-2012