


COCKPIT ASSEMBLY




8. - Attach 1/16" plywood side piece lining up to bottom and front of Firewall.

Work your way back gluing as you go. Making sure everything is lined up and where you want it.


Assembly opposite side in the same manner.

You are now ready to plank the curved and tapered part of the rear section from the seat back.




2. Attach Engine Hatch Frame 6 to location shown and glue in place. Repeat with Engine Hatch Frame 5 and glue in place.

ENGINE HATCH FRAME ASSEMBLY SHEET - 2



3. Glue Engine Hatch Ledger in position shown 2-Places.



- 1. Locate and assemble Engine Hatch Formers with Engine Hatch Side Formers and glue in place.
- 2. Install 1/8" x 1/4" Balsa String in location shown and glue in place.
- 3. Cover with 1/32" plywood sheet.
- 4. Add planking.